



### Input

EXT values are automatically calculated from the data entries and plotted on the graph.



### Chart

A detailed overview of the recipe can be seen.



### Line graph

Displays up to 30 data plot points.



### List

A variety of information can be input and checked from the List screen.

# ATAGO's Coffee Recipe Management App

MY COFFEE RECIPE is an application to assist users in skillfully managing the concentration of their coffee with the experience akin to that of a barista. It allows users to recreate a consistent quality cup of coffee every time.



Data can be exported via email (recipe data).



**Before & After Measurement**  
Zero-set the unit with room temperature water. Make sure that both the unit and water for zero-setting have been acclimated to room temperature.

**Keep the prism clean.**  
Residues left behind may cause erroneous readings. Clean the prism thoroughly after each measurement. Cotton swabs work well for cleaning the edges.

**Tips for Measuring Different Types of Coffee**

**Common for all types**  
The concentration of coffee changes over the course of the extraction process. Gently stirring the coffee will even out the consistency and promote measurement stability.

**French press coffee**  
Pour the coffee into a cup and let it sit undisturbed for a while to allow particles to sink to the bottom. Avoid sampling from the oily surface.

**Espresso**  
Espresso generally contains more particles than drip coffee. Measurement fluctuation by 0.5% is common.

**When cupping**  
Scoop out any floating grounds and oil thoroughly as they may cause unstable measurements.

**ATAGO CO., LTD.**  
<https://www.atago.net/> [overseas@atago.net](mailto:overseas@atago.net)

Headquarters : The Front Tower Shiba Koen, 23rd Floor  
2-6-3 Shiba-koen, Minato-ku, Tokyo 105-0011, Japan  
TEL : 81-3-3431-1943 FAX : 81-3-3431-1945

- ATAGO U.S.A., Inc.
- ATAGO THAILAND Co., Ltd.
- ATAGO ITALIA S.P.A.
- ATAGO RUSSIA Ltd.
- ATAGO KAZAKHSTAN Ltd.
- ATAGO INDIA Instrumentation Pvt. Ltd.
- ATAGO BRASIL Ltda.
- ATAGO CHINA Guangzhou Co., Ltd.
- ATAGO NIGERIA Barista Co., Ltd.

V.05 19041000IR

# PAL-COFFEE

Digital Hand-held "Pocket" Refractometer



Manage and measure the concentration of coffee at a high resolution of 0.01%

